

How do I remove the battery modules before installing the xlbp?

Remove the battery modules before installing the XLBP. Use the battery module handle to carefully slide the battery modules in or out of the XLBP. Do not use the battery module handle to lift or carry the battery module. Failure to follow these instructions can result in equipment damage and minor or moderate injury.

Where can I find a replacement battery for my xlbp?

Refer to the appropriate replacement battery user manual for installation instructions. Contact your dealer or go to the APC by Schneider Electric web site, for information on replacement batteries. This XLBP has swappable battery modules. Refer to the appropriate replacement battery user manual for installation instructions.

How do I install the xlbp connector?

Connect the XLBP connector, labeled RBC 2, to the left hand side (LHS) RBC in rack-mount installation and to the bottom RBC in tower installation, when viewed from front. UPS model may differ in appearance from those depicted in these graphics. The XLBP installation process is identical for all models.

To install one or multiple battery packs into a rack mount, you need to obtain a Rail Kit (Part # SURTRK). The Rail Kit to mount a Smart-UPS RT UPS and External Battery Pack is the same. Mount your external battery pack exactly as you would a UPS, except the battery pack will have two battery trays to remove and replace instead of one. There is ...

6 Smart-UPS SMX120BP External Battery Pack Four-post rack installation su0777b s u 0 8 0 3 a s u 0 8 0 4 a s u 0 8 0 5 a s u 0 8 6 a. Smart-UPS SMX120BP External Battery Pack 7 Connect the External Battery Packs APC Worldwide Customer Support Customer support for this or any other APC product is available at no charge in any of the following ways: o Visit the APC Web ...

CAUTION: Extended Battery Pack (EBP) Installation should be performed by qualified service personnel. 1. Verify that the DC circuit breaker on the rear panel of the EBP is in the OFF position.

SAVE THESE INSTRUCTIONS - This manual contains important instructions that should be followed during installation and maintenance of the Smart-UPS and batteries. Read these instructions carefully and look at the equipment to become familiar with the device before trying to install, operate, service or maintain it.

2 Smart-UPS External Battery Pack SMX48RMBP2U Installation o The UPS can support up to five XLBPs. o Always install the XLBPs at the bottom of the rack with the UPS installed above the ...

Installation Guide APC(TM) Smart-UPS(TM) Ultra External Battery Pack SRTL180RM2UBP and SRTL180RM2UBPJ Important Safety Instructions **SAVE THESE INSTRUCTIONS** - This manual contains

important instructions that should be followed during installation and maintenance of the Smart-UPS and batteries. Read the user documentation to become familiar with the ...

Always install the XLBPs below the UPS in a rack configuration. Connect all battery strings. Failure to do so may cause equipment damage. Each battery weighs 23 kg (51 lbs). Remove ...

Remove the batteries before installing the UPS and external battery packs (XLBPs) in a rack. o Always install XLBPs at the bottom in rack-mount configurations.

installation, even after removal of all battery trays. 1. Position the UPS on the battery pack(s). Reattach the expanded feet according to the instructions in your UPS User Manual. Screw the feet firmly into both the UPS and each battery pack. 2. Screw the rear bracket tie(s) in place between the external battery pack and the UPS, and between each external battery pack if ...

SAVE THESE INSTRUCTIONS - This manual contains important instructions that should be followed during installation and maintenance of the Smart-UPS and batteries. Read these ...

External Battery Pack Installation Inventory Safety and General Information Read the Safety Guide included in the package before installation. This unit is intended for indoor use only. Do not operate this unit in direct sunlight, in contact with fluids, or where there is excessive dust or humidity. Be sure the air vents on the external battery packs (XLBPs) are not blocked. Allow ...

To install one or multiple battery packs into a rack mount, you need to obtain a Rail Kit (Part # SURTRK). The Rail Kit to mount a Smart-UPS RT UPS and External Battery Pack is the same. Mount your external battery pack exactly as you would a UPS, except the battery pack will ...

For installation information, see the Smart-UPS X 2000-3000 VA External Battery Pack Installation guide that is included with the external battery pack. The guide is also available on the enclosed CD and the APC Web site at 4 Smart-UPS X 2000/2200/3000 VA Operation Connect Equipment to the UPS Note: The UPS will charge to 90% capacity in th e ...

Each battery pack model offers scalable runtime solutions via standard daisy-chain installation. The internal battery installation and replacement process uses an easy access, front panel design. Battery modules are user-replaceable and hot-swappable. No expensive technicians are needed, saving time and money. Floor-mount and rackmount ...

Always install the XLBPs below the UPS in a rack configuration. Connect all battery strings. Failure to do so may cause equipment damage. Each battery weighs 23 kg (51 lbs). Remove the batteries before installation in a rack. Rack-mount brackets may differ by model. Use the APC Four-Post Rail Kit. Use the stabilizer bracket provided with the UPS.

Follow steps 1 to 4 to install the Delta external battery pack into the provided rail kit and your rack. See Figure 3. 1 : Adjust the length of the rails according to your rack. Step 2 : Tighten the rails' nuts. Step 3 : Fix the rails on your rack. Step 4 : Insert the Delta external battery pack into your rack and tighten the provided screws.

Web: <https://degotec.fr>